

# EOS Webcam Utility Beta Software

With so many of us relying on video calls to stay connected during these challenging times, the quality of that connection is key. With our EOS Webcam Utility Beta software, turn your compatible Canon camera into a high-quality webcam now!

## Requirements:

- ✔ A camera compatible with EOS Webcam Utility Beta software (see chart below)
- ✔ A USB cable\* to connect the camera to the computer
- ✔ A computer with an internet connection and an operating system capable of running EOS Webcam Utility Beta software

*The following are current system requirements: Windows 10 64-bit, Intel Pentium 1.6GHz or faster processor, with 2 GB or greater of RAM, a display screen resolution of 1,024x768 pixels or more and screen colors medium (16-bit).*

## Compatible Cameras:

Note: Genuine Canon accessories are recommended — see chart on last page for more information.

EOS Series		
EOS-1D X Mark III	EOS R	EOS Rebel T7i*
EOS-1D X Mark II	EOS 6D Mark II*	EOS Rebel T6i
EOS 5DS R	EOS RP*	EOS Rebel T7*
EOS 5DS	EOS 7D Mark II	EOS Rebel T6
EOS 5D Mark IV	EOS 90D*	EOS Rebel SL3*
	EOS 80D*	EOS Rebel SL2*
	EOS 77D*	EOS Rebel T100*
		EOS M6 Mark II*
		EOS M50*
		EOS M200*


  

PowerShot Series		
PowerShot G5 X Mark II*	PowerShot G7 X Mark III*	PowerShot SX70 HS*


\*Camera does not ship with a bundled USB interface cable.

# How to Download:


1. Open your web browser and either go directly to our [EOS Webcam Utility Website](#) OR follow the steps below to navigate through the [Canon USA Website](#).




2. If navigating through the [Canon USA Website](#), at the top of the main page, find the "Search Area."



3. Type "EOS Webcam Utility Beta" in the "Search Area" and hit enter.



4. Select your camera model from the list displayed. You will then be redirected to the Download Page.



## 5. Select and download “EOS Webcam Utility Beta.”


The screenshot shows the Canon website for the EOS M200 EF-M 15-45mm IS STM Kit. The page features a navigation bar at the top, a COVID-19 update banner, and a product image of the camera. Below the image are buttons for 'VIEW MORE DETAILS' and 'FIND A DEALER'. The 'Drivers & Downloads' section is expanded, showing a table of optional software. The table has columns for 'File Name', 'Date', and 'File Size'. The entry 'EOS Webcam Utility Beta 01/N for Windows' is highlighted, and a black arrow points to the 'DOWNLOAD' button next to it.

File Name	Date	File Size
EOS Webcam Utility Beta 01/N for Windows	04/24/20	24.191 MB
Digital Photo Professional 4.12.20 for Windows	04/07/20	288.41 MB


## 6. Once the software download is complete, locate the “EOS Webcam Utility Beta Installation Package” in your computer’s “Downloads” folder. The “Installation Package” will be called “EOS-Webcam-Utility-Beta-WIN0.9.0.zip.” Open the .zip file.

The screenshot shows a Windows File Explorer window with the 'Downloads' folder selected. The folder contains a zip file named 'EOS-Webcam-Utility-Beta-WIN0.9.0.zip'. The window title is 'This PC > Downloads >'. The left sidebar shows the 'Downloads' folder selected.


7. Open the Windows Installer Package file.




8. You will be greeted by the installer "Welcome" screen. Click "Next."




**9.** Read through the License Agreement and if you agree, click "I agree." Then, click "Next."




**10.** The installer is now ready to begin. Click "Next" to proceed.




11. You will see the installer ask permission to make changes to your computer. Select "Yes" to allow the installer to begin.




12. Wait for the installation to complete.



**13.** Click "Close" to complete the installer dialogue.



**14.** At this point, it is important to save any documents that you may be working on, close all applications that you have running and then RESTART YOUR COMPUTER.






- 15.** Once restarted, using your USB cable, connect one end of the USB cable to your camera, and then connect the other end to your computer.



- 16.** Turn camera on. It is recommended to use Movie Mode. Set this with your camera's Mode Dial, Mode Switch or Mode Button interface.



- 17.** Lastly, open your web conferencing app of choice. Find the "audio/video settings" menu and set "EOS Webcam Utility Beta" as the camera of choice. Confirm that your built-in microphone is selected as your "microphone" (Note: audio is not transmitted from the camera).
- 18.** Enjoy easy-to-use, high-quality video conferencing with EOS Webcam Utility Beta software functionality.

For troubleshooting and the latest information on support for EOS Webcam Utility Beta software, please visit the Canon Forum Support thread: [Canon.us/forum-eoswebcamutility](https://www.canon.us/forum-eoswebcamutility)

# Compatible Accessories:

Note: Genuine Canon accessories are recommended.

Camera Model	Suggested USB Interface Cable	Suggested Optional AC Adapter Accessories
EOS-ID X Mark III	IFC-100U (to USB C)	AC Adapter AC-E19 with DC Coupler DR-E19
EOS-ID X Mark II	IFC-150U II	AC Adapter AC-E19 with DC Coupler DR-E19
EOS 5DS R	IFC-150U II	AC Adapter AC-E6N with DC Coupler DR-E6
EOS 5DS	IFC-150U II	AC Adapter AC-E6N with DC Coupler DR-E6
EOS 5D Mark IV	IFC-150U II	AC Adapter AC-E6N with DC Coupler DR-E6
EOS R	IFC-100U (to USB C)	AC Adapter AC-E6N with DC Coupler DR-E6
EOS 6D Mark II	IFC-400PCU*	AC Adapter AC-E6N with DC Coupler DR-E6
EOS RP	IFC-100U (to USB C)*	AC Adapter AC-E6N with DC Coupler DR-E18
EOS 7D Mark II	IFC-150U II	AC Adapter AC-E6N with DC Coupler DR-E6
EOS 90D	IFC-600PCU*	AC Adapter AC-E6N with DC Coupler DR-E6
EOS 80D	IFC-400PCU*	AC Adapter AC-E6N with DC Coupler DR-E6
EOS 77D	IFC-400PCU*	AC Adapter AC-E6N with DC Coupler DR-E18
EOS Rebel T7i	IFC-400PCU*	AC Adapter AC-E6N with DC Coupler DR-E18
EOS Rebel T6i	IFC-130U	AC Adapter AC-E6N with DC Coupler DR-E18
EOS Rebel T7	IFC-400PCU*	Compact Power Adapter CA-PS700 with DC Coupler DR-E10
EOS Rebel T6	IFC-130U	Compact Power Adapter CA-PS700 with DC Coupler DR-E10
EOS Rebel SL3	IFC-600PCU*	AC Adapter AC-E6N with DC Coupler DR-E18
EOS Rebel SL2	IFC-400PCU*	AC Adapter AC-E6N with DC Coupler DR-E18
EOS M6 Mark II	IFC-100U (to USB C)*	Compact Power Adapter CA-PS700 with DC Coupler DR-E17
EOS M50	IFC-600PCU*	Compact Power Adapter CA-PS700 with DC Coupler DR-E17
EOS M200	IFC-600PCU*	Compact Power Adapter CA-PS700 with DC Coupler DR-E12
EOS Rebel T100	IFC-400PCU*	N/A
PowerShot G5 X Mark II	IFC-100U (to USB C)*	N/A (Note: USB Power Adapter PD-E1 cannot be used at the same time as USB Interface Cable)
PowerShot G7 X Mark III	IFC-100U (to USB C)*	N/A (Note: USB Power Adapter PD-E1 cannot be used at the same time as USB Interface Cable)
PowerShot SX70 HS	IFC-600PCU*	N/A

\*Camera does not ship with a USB interface cable.

